

Rebel Trike XR Owner's Manual



www.FatTireGolfScooter.com

service@fattiregolf scooter.com

Phone: 602-826-0222

Fax: 602-971-0816



Table of Contents

Page 3- Specifications

Page 4- General Operation

Page 5- Safety Information

Page 6- Warranty

Rebel 3-Wheel Specifications

- High-output, High Torque Waterproof Motor
- (2) 60v Lithium Ion Battery Packs
- Approx. 15 mph speed (locked for golf course safety)
- Weight Capacity 300 lbs.
- Scooter Weight– 190 lbs.
- 225/40-10 Tubeless Tires on Chrome Rims
- 85” L x 37” W x 44” H
- Packing crate– 82” L x 42” W x 50” H, 440 lbs.
- Front and Rear Hydraulic Disc Brakes
- 60 volt, 3amp Charger
- LED Headlight
- One Year Parts Warranty
- Cooler
- Sand Bottle
- Scorecard Holder

Operation of Fat Tire Golf Trike XR

1. Insert key and turn clockwise. Display will light up showing the battery status. Turn key one more position to activate front headlight
2. When ready to ride, with both feet on the floorboard, **slowly** twist the throttle toward you while keeping your left fingers **on the brake handle, ready to brake**. Drive a very short distance and apply the left brake. Do this 2-3 times until you get familiar with the throttle and braking.
3. If parking on a hill, apply the left safety brake by pulling in on the handle and pushing down the locking pin. To release, simply pull in the lever and release the locking tab.



Charging the battery:

The Rebel Fat Tire Golf Scooter Trike XR is equipped with dual 60 volt 20ah lithium ion batteries. The batteries can be charged on-board through the port in front of the floorboard (or the battery can be removed from under the seat or floorboard and charged remotely). It takes approximately 6 hours to fully charge the battery. The charger has a red light to indicate the battery is being charged, and a green light when fully charged. **Remove the charger from the battery after charging.**



Safety Tips

Safety tips for the Fat Tire Golf Scooter (FTGS) include:

1. Pay attention to your surroundings at all times. Make sure you are comfortable with the throttle and hand brakes before going out on the course.
2. **Be careful with your speed.** Avoid obstacles or sharp turns. **Use your brakes when going downhill to avoid excessive speed.**
3. The FTGS should be kept **at least 10 feet from the tees and greens.**
4. **Do not** ever put multiple people on the same FTGS.
5. Be careful and always pay attention.
6. **Stay clear of mud, sand, loose dirt or gravel, and water.**
7. **The FTGS is not a toy** and is not to be ridden by children under the age of 18.
8. Do not enter areas that are identified as not safe for the FTGS
9. **Never ride down hills that put your safety and the FTGS at risk. Walk your FTGS down steep slopes and areas where advised by the course.**
10. Do not take the FTGS over curbs as this can cause serious damage.
11. **Do not operate FTGS under the influence of alcohol or drugs.**

Warranty

The Fat Tire Golf Scooter warranties all parts against manufacturers defects for a period of ONE year.

FTGS will, at their discretion, replace or repair any item found to be defective, including:

- Frame
- Motor
- Controller
- Battery
- Throttle
- Handlebar switches
- Brake Calipers and Master Cylinders
- Bag holder and attachment brackets
- Aluminum brackets for cooler and scorecard holder

NOTE: Wear items such as tires, brake pads, rubber parts, seat fabric and cushions, cooler, sand bottle, light bulbs, etc. are NOT included.

Labor costs are NOT covered by warranty

ANY DAMAGE OR DEFECT OCCURRING FROM THE MISUSE OF THE SCOOTER IS
NOT COVERED.

Warranty starts from the time scooter is delivered to your home or facility.

Fat Tire Golf Scooter
13232 N. Cave Creek Rd.
Phoenix, AZ 85022
www.fattiregolfscooter.com